

WireReady®

Telephone system Wiring Lightning Protection Notice

In order for your telephone, headset and computer modem to be protected from lightning strikes that can come through the phone lines, the same surge suppressor/ battery backup box that protects the computer should also be used to protect the telephone equipment.

Make sure your telephone lines are connected this way:

1. From wall jack to battery backup phone line IN jack.
2. From phone line IN jack on UPS to modem LINE IN on the computer.
3. From the modem LINE OUT on the computer to the telephone.
4. From the telephone handset jack to the Virtuoso.
5. From the Virtuoso to the telephone handset.

Pay special attention to numbers 1 and 2; this is necessary to protect your system. If you do not have a the telephone line from the wall first going to the UPS unit, get an extra 7 foot phone cord (or call us) and connect the telephone line through the battery backup UPS BEFORE the line connects to the computer's modem.